

# POLYSWEEP INSTALLATION STEPS

## Step 1: Sweep PolySweep into joints



## Step 2: Compact pavers





## POLYSWEEP INSTALLATION STEPS

### Step 3: Re-sweep PolySweep into joints



### Step 4: Re-compact pavers





## POLYSWEEP INSTALLATION STEPS

**Step 5: Remove excess PolySweep from any inside corners**



**Step 6: Final sweep**





## **POLYSWEEP INSTALLATION STEPS**

**Step 7: Gently blow any remaining sand off pavers BEFORE wetting**



**Step 8: Sand should be at bottom of chamfer or 1/8" from top**





## POLYSWEEP INSTALLATION STEPS

**Step 9: Begin watering gently by using a fine mist**



**Step 10: Gradually add more moisture 3-4 times. Stop when you see any foam in joints (floating polymers). \*Use a leaf blower to blow any excess water off textured pavers**





## POLYSWEEP INSTALLATION STEPS

**Step 11: Check joints to make sure sand is moist (3/4" – 1")**



**Step 12: Completed Project!**

